

# CMG

SOLUTIONS, not just products

Edition 1 Issue 1



## AURORA Soft Starters

LPRB User Manual



## SOLUTIONS, not just products

### *Specialists in Electric Motors, AC Drives & Soft Starters*

At CMG we offer customised packages to the most demanding industrial markets. Our success is built on a strong commitment to our customers' needs and a willingness to find the best solution possible. We have been in business since 1948 so you can be confident our experience and knowledge is second to none.

Over the past 62 years, CMG Pty Ltd has enjoyed a solid reputation as a quality supplier for electric motors, variable speed drives and soft starters.

CMG's commitment to quality products is supported by our ISO 9001 and NATA laboratory accreditations.

Our electric motor range now covers low voltage motors up to 1400kW, medium voltage up to 2.5MW and high voltage up to 13MW.

Additionally, we can supply variable speed drives up to 5MW and soft starters up to 1MW.

Our company has extensive experience in providing tailored solutions for even the most difficult of applications.

From design concept through to technical evaluation of your specific requirements, our dedicated team is with you every step of the way.

In April 2010, CMG and its group of companies joined the Regal Beloit Corporation (RBC). RBC is an international manufacturer of electrical and mechanical motor control components with head quarters in Beloit, Wisconsin. RBC's strength is in its market diversity as it serves an expansive array of markets from heavy industry to high technology.

***"We convert power into motion to help  
the world run more efficiently."***

REGAL BELOIT  
BUSINESS PURPOSE



» Electric Motors



» AC Drives



» Soft Starters

# Caution Statements

Caution Statements cannot cover every potential cause of equipment damage but can highlight common causes of damage. It is the installer's responsibility to read and understand all instructions in this manual prior to installing, operating or maintaining the soft starter, to follow good electrical practice including applying appropriate personal protective equipment and to seek advice before operating this equipment in a manner other than as described in this manual.

- Isolate the soft starter completely from the power supply before attempting any work on the starter or motor.
- Cables to the control inputs must be segregated from mains voltage and motor cabling.
- Some electronic contactor coils are not suitable for direct switching with PCB mount relays. Consult the contactor manufacturer/supplier to confirm suitability.
- Do not apply incorrect voltages to the control input terminals.
- Do not connect power factor correction capacitors to the output of Aurora LPRB soft starters. If static power factor correction is employed, it must be connected to the supply side of the soft starter.

The examples and diagrams in this manual are included solely for illustrative purposes. The information contained in this manual is subject to change at any time and without prior notice. In no event will responsibility or liability be accepted for direct, indirect or consequential damages resulting from the use or application of this equipment.



## **WARNING - ELECTRICAL SHOCK HAZARD**

Aurora LPRB soft starters contain dangerous voltages when connected to mains voltage. Only a qualified electrician should carry out the electrical installation. Improper installation of the motor or the soft starter may cause equipment failure, serious injury or death. Follow this manual and local electrical safety codes.



## **GROUNDING AND BRANCH CIRCUIT PROTECTION**

It is the responsibility of the user or person installing the soft starter to provide proper grounding and branch circuit protection according to local electrical safety codes.




## **SHORT CIRCUIT**

Aurora LPRB soft starters are not short circuit proof. After severe overload or short circuit, the operation of the soft starter should be fully tested by an authorised service agent.


# Mechanical Installation

## Dimensions and Weights



Model	A	B	C	D	E	F	G	H	Weight
	mm (inch)	mm (inch)	mm (inch)	mm (inch)	mm (inch)	mm (inch)	mm (inch)	mm (inch)	kg (lb)
LPRB-0018 LPRB-0034 LPRB-0042 LPRB-0048 LPRB-0060	98 (3.85)	82 (3.22)	201 (7.91)	188 (7.40)	165 (6.49)	55 (2.16)	90.5 (3.6)	23 (0.9)	2.2 (4.85)
LPRB-0075 LPRB-0085 LPRB-0100	145 (5.70)	124 (4.88)	215 (8.46)	196 (7.71)	193 (7.59)	-	110.5 (4.4)	37 (1.5)	4.0 (8.81)
LPRB-0140 LPRB-0170 LPRB-0200	200 (7.87)	160 (6.29)	240 (9.44)	216 (8.50)	214 (8.42)	-	114.5 (4.5)	51 (2.0)	6.5 (14.33)








## Physical Installation




<b>1</b>	LPRB-0018 ~ LPRB-0100: Allow 100 mm (3.9 inch) between soft starters. LPRB-0140 ~ LPRB-0200: Allow 200 mm (7.9 inch) between soft starters.
<b>2</b>	LPRB-0018 ~ LPRB-0100: Allow 50 mm (2.0 inch) between the soft starter and solid surfaces. LPRB-0140 ~ LPRB-0200: Allow 200 mm (7.9 inch) between the soft starter and solid surfaces.
<b>3</b>	Soft starters may be mounted side by side with no clearance.
<b>4</b>	The soft starter may be mounted on its side. Derate the soft starter's rated current by 15%.

# Electrical Installation

## Power Terminations

	L1/1, L2/3, L3/5, T1/2, T2/4, T3/6 mm <sup>2</sup> (AWG)			A1, A2, A3, 01, 02, B4, B5, 13, 14, 23, 24 mm <sup>2</sup> (AWG)	
	0018 - 0060	0075 - 0100	0140 - 0200	0018 - 0200	
	10 - 35 (8 - 2)  14 (0.55) mm (inch)	25 - 50 (4 - 1/10)  14 (0.55) mm (inch)	N.A.  11 (0.43) 8.5 (0.33) mm (inch)	0.14 - 1.5 (26 - 16)  6 (0.24) mm (inch)	
	Torx (T20) 3 Nm 2.2 ft-lb	Torx (T20) 4 Nm 2.9 ft-lb	N.A.	N.A.	
	7 mm 3 Nm 2.2 ft-lb	7 mm 4 Nm 2.9 ft-lb	N.A.	3.5 mm 0.5 Nm max 4.4 in-lb max	

## Control Circuits




### WARNING

Always apply control voltage before (or with) mains voltage.

## Motor Thermistor

Motor thermistors can be connected directly to the Aurora LPRB terminals B4, B5. If motor thermistors are not used, there must be a link between B4, B5 (the Aurora LPRB is supplied with a link fitted).



### WARNING

Isolate the soft starter completely from the power supply before attempting any work on the starter or motor. Control terminals may be at phase voltage potential.

## Outputs

### Main Contactor Output

The Main Contactor output (terminals 13, 14) closes as soon as the soft starter receives a start command and remains closed while the soft starter is controlling the motor (until the motor starts a coast to stop, or until the end of a soft stop). The Main Contactor output will also open if the soft starter trips.

The Main Contactor output can be used to directly control a main contactor coil.

### Programmable Output

The programmable output relay (terminals 23, 24) can be used to signal either trip or run status. This relay is normally open.

Trip:


The relay closes when the Aurora LPRB trips. The relay can be used to operate the shunt-trip mechanism of an upstream circuit breaker (in order to isolate the motor branch circuit), or to signal the trip to an automation system or externally. The relay will open when the trip is reset.

Run:


The relay operates when the soft start is complete, the bypass relays are closed and full voltage is being applied to the motor. The relay can be used to operate a contactor for power factor correction capacitors, or to signal soft starter run status to an automation system.

## Electrical Schematics

*Soft starter installed with a system protection circuit breaker complete with a shunt trip device*




*Soft starter installed with a system protection circuit breaker and main contactor*


















<b>M</b>	Motor (three phase)
<b>KM1</b>	Main contactor
<b>13, 14</b>	Main contactor output
<b>23, 24</b>	Programmable output (set to Trip)

# Adjustments



<b>1</b>	Current Ramp
<b>2</b>	Current Limit
<b>3</b>	Motor Trip Class
<b>4</b>	Motor FLC
<b>5</b>	Soft Stop Time
<b>6</b>	Excess Start Time
<b>7</b>	Auxiliary Relay Function
<b>8</b>	Phase Sequence Protection

<p><b>1</b> Current Ramp</p> 	<p>Select the initial start current (A) and ramp time (B). Current ramp starting extends the time soft starter takes to reach the current limit and is suitable for generator set supplies, loads requiring an extended start time or applications with extreme load variation between starts. The ramp time does not control the time the motor will take to reach full speed.</p> 
<p><b>2</b> Current Limit</p> 	<p>Select the current limit (C). The current limit is the maximum level of current the soft starter will deliver to the motor during the soft start.</p> 
<p><b>3</b> Motor Trip Class</p> 	<p>Select the trip class for motor overload protection. The trip class reflects the maximum time (in seconds) that the motor can run at locked rotor current. The Motor Trip Class setting assumes a locked rotor current of 600%.  Setting the motor trip class to "Off" disables motor overload protection.</p> 
<p><b>4</b> Motor Full Load Current</p> 	<p>Configure the soft starter to match the motor's full load current (FLC). Configure according to the motor's nameplate current. Divide the motor's FLC by the soft starter's maximum current rating (on the soft starter's nameplate label).</p> 

<p><b>5</b></p> 	<p><b>Soft Stop Time</b></p> <p>Select the soft stop ramp time (D). Soft stop extends the time soft starter takes to reduce voltage to zero. The ramp time does not control the time the motor will take to stop completely.</p>													
<p><b>6</b></p> 	<p><b>Excess Start Time</b></p> <p>Configure the soft starter's excess start time protection. Select a time slightly longer than the motor requires for a normal healthy start. The soft starter will trip if the start does not complete within the selected time (E).</p>													
<p><b>7</b></p> 	<p><b>Auxiliary Relay Function</b></p> <p>Select the function of the soft starter's programmable output (terminals 23, 24). When set to "Run", the relay will operate when the soft start is complete. When set to "Trip", the relay will operate when the soft starter trips.</p>													
<p><b>8</b></p> 	<p><b>Phase Sequence Protection</b></p> <p>Configure the soft starter's phase sequence protection. Select the allowable phase sequences. A setting of "Fwd" allows forward sequence (positive rotation) only and a setting of "Any" defeats the protection.</p>	<table border="1"> <thead> <tr> <th colspan="2"></th> <th>FWD</th> <th>ANY</th> </tr> </thead> <tbody> <tr> <td>L1 L2 L3</td> <td>soft starter</td> <td>✓</td> <td>✓</td> </tr> <tr> <td>L1 L2 L3</td> <td>soft starter</td> <td>✗</td> <td>✓</td> </tr> </tbody> </table>			FWD	ANY	L1 L2 L3	soft starter	✓	✓	L1 L2 L3	soft starter	✗	✓
		FWD	ANY											
L1 L2 L3	soft starter	✓	✓											
L1 L2 L3	soft starter	✗	✓											




**NOTE**

Auxiliary relay function and phase rotation are configured using a shared switch. Set the auxiliary relay function as required, then set phase rotation protection.



# Troubleshooting











## LEDs



LED Status	Ready	Run
Off	No control power	Motor not running
On	Ready	Motor running at full speed
Flash	Starter tripped	Motor starting or stopping

## Trip Codes

The Ready LED will flash a different number of times to indicate the cause of the trip.

Ready LED	Description
 x 1	Power Circuit: Check mains supply (L1, L2, L3), motor circuit (T1, T2, T3), soft starter SCRs and bypass relays.
 x 2	Excess Start Time: Check load, increase Current Limit or adjust Excess Start Time setting.
 x 3	Motor Overload: Allow motor to cool, reset soft starter and restart. The soft starter cannot be reset until the motor has cooled.
 x 4	Motor Thermistor: Check motor ventilation and thermistor connection B4, B5. Allow motor to cool.
 x 5	Phase Imbalance: Check for mains supply or line current imbalance (L1, L2, L3).
 x 6	Supply Frequency: Check mains voltage is available and supply frequency is in range.
 x 7	Phase Rotation: Check for correct phase rotation.
 x 8	Network Communication Failure (between module and network): Check network connections, settings and configuration.
 x 9	Starter Communication Failure (between starter and module): Remove and re-fit accessory module.
 x 10	Bypass Overload: Starter rating may be too low for the application.

## Protections

The Aurora LPRB includes the following types of protection for the motor and starter:

### Excess Start Time Protection

The Aurora LPRB will trip on excess start time if the motor does not successfully start within the time selected in the Excess Start Time setting. This may indicate that the load has stalled.

If the soft starter frequently trips on excess start time:

- check that the Current Limit setting is high enough for the application
- check that the Excess Start Time setting is long enough for the application
- check that the load has not stalled or increased since the soft starter was installed

## Motor Overload Protection

The Aurora LPRB will trip on motor overload if it calculates that the motor has been running above its operating range for longer than the time selected in the Motor Trip Class setting. Motor Trip Class should be set to match the motor's locked rotor time. If this information is not available from the motor datasheet, use the default setting (Motor Trip Class = 10). Using a higher setting can damage the motor.



### NOTE

Motor overload protection does not protect the soft starter, and does not protect the motor from short circuit.

## Phase Imbalance Protection

The Aurora LPRB will trip on phase imbalance if the highest and lowest currents on the three phases vary by an average of 30% for more than 3 seconds. Phase imbalance protection is not adjustable, and is only active when the average motor current is 50% or more of the programmed motor FLC.

If the soft starter frequently trips on phase imbalance:

- check that there is no imbalance on the mains voltage (on the input side of the soft starter)
- insulation test the motor
- move all input cables over one position (move L1 cable to L2, move L2 cable to L3, move L3 cable to L1) to rule out a cabling fault

## Supply Frequency Protection

The soft starter will trip on supply frequency if the frequency rises above 72 Hz or falls below 40 Hz for more than five seconds while the soft starter is running. These trip points are not adjustable.

In pre-start, starting and stopping modes the high and low frequency limits both apply with no time delay.

A supply frequency trip will also occur if:

- all three input phases are lost while the soft starter is running
- all three input phases fall below 120 VAC at start or while the soft starter is running
- the line contactor opens while running

## Bypass Overload Protection

Bypass overload protection protects the soft starter from severe operating overloads while running. The protection is not adjustable and has two components:

- The soft starter will trip if it detects overcurrent at 600% of the programmed motor full load current.
- The soft starter models the temperature of the internal bypass relays and will trip if the temperature exceeds the safe operating level.

If the trip occurs frequently, this indicates that the soft starter has not been selected correctly for the application.

## Reset

Trips can be cleared by pressing the Reset button on the soft starter, sending a Reset command from the serial communications network, or by switching the control inputs.

To clear a trip via the control inputs, the soft starter requires a closed to open transition on the stop input (O2).

- In three-wire control, use the external stop button to momentarily open the stop input (open A1-O2).
- In two-wire control, if the soft starter tripped with a start signal present, remove the start signal (open A1 to O1, O2).
- In two wire control, if the Aurora LPRB tripped with no start signal present (eg Aurora LPRB motor thermistor trip), apply then remove the start signal (close then reopen A1 to O1, O2).

The Reset button is located on the front of the unit, above the adjustment switches.

The soft starter will trip again immediately if the cause of the trip still exists.

# Accessories

## Finger Guard Kit

Finger guards may be specified for personnel safety and can be used on Aurora LPRB soft starter models 0140–0200. Finger guards fit over the soft starter terminals to prevent accidental contact with live terminals. Finger guards provide IP20 protection when used with cable of diameter 22 mm or greater.

## Remote Operator

The Remote Operator can control and monitor the soft starter's performance. Functionality includes:

- Operational control (Start, Stop, Reset, Quick Stop)
- Starter status monitoring (Ready, Starting, Running, Stopping, Tripped)
- Performance monitoring (motor current, motor temperature)
- Trip code display
- 4-20 mA analog output (Motor Current)

## Communication Modules

Aurora LPRB soft starters support network communication using the Profibus, DeviceNet and Modbus RTU protocols.

## PC Software

AuroraMaster can be used with CMG soft starters to provide the following functionality for networks of up to 99 soft starters:

- Operational control (Start, Stop, Reset, Quick Stop)
- Starter status monitoring (Ready, Starting, Running, Stopping, Tripped)
- Performance monitoring (motor current, motor temperature)

To use AuroraMaster with the Aurora LPRB, the soft starter must be fitted with a USB module, Modbus Module or a Remote Operator.

# Specifications

## General Technical Data

### Mains Supply

Mains voltage (L1, L2, L3)	
4	3 x 200 VAC ~ 440 VAC (+ 10% / - 15%)
6	3 x 200 VAC ~ 575 VAC (+ 10% / - 15%)
Mains frequency (at start)	45 Hz to 66 Hz
Rated insulation voltage	600 VAC
Form designation	Bypassed semiconductor motor starter form 1

### Control Supply

Control voltage	110-240 VAC (+ 10% / - 15%) or 380-440 VAC (+ 10% / - 15%)
Current consumption (during run)	< 100 mA
Current consumption (inrush)	10 A

### Inputs

Start (terminal 01)	Normally open 150 kΩ @ 300 VAC and 5.6 kΩ @ 24 VAC/VDC
Stop (terminal 02)	Normally closed 150 kΩ @ 300 VAC and 5.6 kΩ @ 24 VAC/VDC

### Outputs

Main contactor relay (terminals 13, 14)	Normally open 6 A, 30 VDC resistive / 2 A, 400 VAC, AC11
Programmable relay (terminals 23, 24)	Normally open 6 A, 30 VDC resistive / 2 A, 400 VAC, AC11

### Environmental

Degree of protection LPRB-0018 to LPRB-0100	IP20
Degree of protection LPRB-0140 to LPRB-0200	IP00
Operating temperature	-10 °C to +60 °C
Storage temperature	-25 °C to +60 °C (to +70 °C for less than 24 hours)
Humidity	5% to 95% Relative Humidity
Pollution degree	Pollution Degree 3
Vibration	IEC 60068 Test Fc Sinusoidal 4 Hz to 13.2 Hz: ± 1 mm displacement 13.2 Hz to 200 Hz: ± 0.7 g

### EMC Emission

Equipment class (EMC)	Class A
Conducted radio frequency emission	0.15 MHz to 0.5 MHz: < 90 dB (µV) 0.5 MHz to 5 MHz: < 76 dB (µV) 5 MHz to 30 MHz: 80-60 dB (µV)
Radiated radio frequency emission	30 MHz to 230 MHz: < 30 dB (µV/m) 230 MHz to 1000 MHz: < 37 dB (µV/m)

This product has been designed as Class A equipment. Use of this product in domestic environments may cause radio interference, in which case the user may be required to employ additional mitigation methods.

### EMC Immunity

Electrostatic discharge	4 kV contact discharge, 8 kV air discharge
Radio frequency electromagnetic field	0.15 MHz to 1000 MHz: 140 dB (µV)
Rated impulse withstand voltage (Fast transients 5/50 ns)	2 kV line to earth, 1 kV line to line
Voltage dip and short time interruption	100 ms (at 40% nominal voltage)
Harmonics and distortion	IEC61000-2-4 (Class 3), EN/IEC61800-3

### Short Circuit

Rated short-circuit current LPRB-0018 to LPRB-0048	5 kA
Rated short-circuit current LPRB-0060 to LPRB-0200	10 kA

### Heat Dissipation

During Start	3 watts / ampere
During Run	10 watts typical

**Standards Approvals**

C✓ ..... IEC 60947-4-2  
 CE ..... IEC 60947-4-2

**Operational Life**

LPRB-0018-0100 ..... 1,000,000 operations  
 LPRB-0140-0200 ..... 30,000 operations

**Part Number Logic**

L	P	R	B	-	0	0	1	8	B	4	1	0	
1	2	3	4		5-9				10	11	12	13	Suffix

**Position 1-3**

LPR = LPR series soft starters

**Position 4 - Series**

A = Advanced digital model  
 B = Basic compact model

**Position 5-9 - Rated Current**

XXXX = Starter FLC rating (see selection tables)

**Position 10 - Bypass**

B = Integral bypass  
 C = Continuous connection (no bypass)

**Position 11 - Supply Voltage**

4 = 200 ~ 440 VAC  
 6 = 200 ~ 575 VAC

**Position 12 - Control Voltage**

1 = 110-240 VAC or 380-440 VAC

**Position 13 - Interface**

0 = No feedback display  
 1 = Feedback display included

**Current Ratings**

	AC53b 4-6:354 < 1000 metres		AC53b 4-20:340 < 1000 metres	
	40 °C	50 °C	40 °C	50 °C
LPRB-0018	18 A	17 A	17 A	15 A
LPRB-0034	34 A	32 A	30 A	28 A
LPRB-0042	42 A	40 A	36 A	33 A
LPRB-0048	48 A	44 A	40 A	36 A
LPRB-0060	60 A	55 A	49 A	45 A
	AC53b 4-6:594 < 1000 metres		AC53b 4-20:580 < 1000 metres	
	40 °C	50 °C	40 °C	50 °C
LPRB-0075	75 A	68 A	65 A	59 A
LPRB-0085	85 A	78 A	73 A	67 A
LPRB-0100	100 A	100 A	96 A	87 A
LPRB-0140	140 A	133 A	120 A	110 A
LPRB-0170	170 A	157 A	142 A	130 A
LPRB-0200	200 A	186 A	165 A	152 A

## Semiconductor Fuses

Semiconductor fuses can be used with Aurora LPRB soft starters to reduce the potential for damage to SCRs from transient overload currents and for Type 2 coordination. Aurora LPRB soft starters have been tested to achieve Type 2 coordination with semiconductor fuses. Suitable Bussmann and Ferraz semiconductor fuses are detailed below.

Model	SCR I <sup>2</sup> T (A <sup>2</sup> S)	Ferraz Fuse European/IEC Style (North American Style)	Bussmann Fuse Square Body (170M)	Bussmann Fuse British Style (BS88)
LPRB-0018	1150	6.6URD30xxxA0063 (A070URD30xxx0063)	170M-1314	63 FE
LPRB-0034	8000	6.6URD30xxxA0125 (A070URD30xxx0125)	170M-1317	160 FEE
LPRB-0042	10500	6.6URD30xxxA0160 (A070URD30xxx0160)	170M-1318	160 FEE
LPRB-0048	15000	6.6URD30xxxA0160 (A070URD30xxx0160)	170M-1318	180 FM
LPRB-0060	18000	6.6URD30xxxA0160 (A070URD30xxx0160)	170M-1319	180 FM
LPRB-0075	51200	6.6URD30xxxA0250 (A070URD30xxx0250)	170M-1321	250 FM
LPRB-0085	80000	6.6URD30xxxA0315 (A070URD30xxx0315)	170M-1321	250 FM
LPRB-0100	97000	6.6URD30xxxA0315 (A070URD30xxx0315)	170M-1321	250 FM
LPRB-0140	168000	6.6URD31xxxA0450 (A070URD31xxx0450)	170M-1322	500 FMM
LPRB-0170	245000	6.6URD31xxxA0450 (A070URD31xxx0450)	170M-3022	500 FMM
LPRB-0200	320000	6.6URD31xxxA0450 (A070URD31xxx0450)	170M-3022	500 FMM

xxx = Blade Type. Contact Ferraz for options.



## HEAD OFFICE

19 Corporate Ave / PO Box 2340  
Rowville VIC 3178 AUSTRALIA  
info@cmggroup.com.au  
Tel: +61 (0)3 9237 4000  
Fax: +61 (0)3 9237 4010

## AUSTRALIA

Sales : 1300 888 853  
Support : 1800 676 722  
www.cmggroup.com.au

CMG Pty Ltd  
ABN 99 005 118 114

## VICTORIA

19 Corporate Ave  
Rowville VIC 3178  
Tel: +61 (0)3 9237 4040  
Fax: +61 (0)2 9237 4050

## NEW SOUTH WALES

8/26 Powers Road  
Seven Hills NSW 2147  
Tel: +61 (0)2 9674 1555  
Fax: +61 (0)2 9674 4652

## NORTH NEW SOUTH WALES

13B Old Punt Road  
Tomago NSW 2322  
Tel: +61 (0)2 4016 1780  
Fax: +61 (0)2 4016 1785

## QUEENSLAND

1/6-8 Radium Street  
Crestmead QLD 4132  
Tel: +61 (0)7 3803 2033  
Fax: +61 (0)7 3803 2683

## NORTH QUEENSLAND

Cnr. John Vella Drive & Connors Rd  
Paget, Mackay NQLD 4740  
Tel: +61 (0)7 4952 6244  
Fax: +61 (0)7 4952 6277

## WESTERN AUSTRALIA

21 Colin Jamieson Drive  
Welshpool WA 6106  
Tel: +61 (0)8 6253 3700  
Fax: +61 (0)8 6253 3710

## NEW ZEALAND

Sales : 0800 676 722  
www.cmggroup.co.nz

CMG Electric Motors (NZ) Ltd  
NZCN : 567 351

## AUCKLAND

315A Rosebank Road  
Rosebank, Avondale, Auckland  
Tel: +64 (0)9 820 3550  
Fax: +64 (0)9 820 8504

## CHRISTCHURCH

Cnr Lunns & Annex Road  
Middleton, Christchurch  
Tel: +64 (0)3 348 3740  
Fax: +64 (0)3 348 3760

## ROTORUA

51 Pururu Street, Rotorua  
Tel: +64 (0)7 347 8624  
Fax: +64 (0)7 347 8629

## CAMBRIDGE

13 Carters Crescent, Cambridge  
Tel: +64 (0)7 827 4986  
Fax: +64 (0)7 827 4819

## ASIA PACIFIC

www.cmggroup.com.sg

## SINGAPORE

CMG Electric Motors (Asia Pacific) Pte Ltd  
Registration No. 200414611G  
12 Tuas Loop  
Singapore 637346  
Tel: +65 6863 3473  
Fax: +65 6863 3476

## MALAYSIA

CMG Electric Motors (Malaysia) Sdn. Bhd  
Registration No. 796093-K  
6536A Jalan Bukit Kemuning,  
Batu 6, Seksyen 34  
40470 Shah Alam, Malaysia  
Tel: +603 5124 9217  
Fax: +603 5124 6195  
www.cmggroup.com.my

## SOUTH AFRICA

www.cmggroup.co.za

CMG Electric Motors South Africa Pty Ltd  
Registration No. 2003/001379/07

## JOHANNESBURG

268B Fleming Road  
Meadowdale, Germiston  
Johannesburg 1614  
Tel: +27 (0)11 453 1930  
Fax: +27 (0)11 453 9560

## DURBAN

Unit 13 Heron Park  
80 Corobrik Road  
Riverhorse Valley Estate  
Durban 4017  
Tel: +27 (0)31 569 5551  
Fax: +27 (0)31 569 5549

## MIDDELBURG

Unit 6, 2 Rand Street  
Industrial Area  
Middelburg 1050  
Tel: +27 (0)13 246 1902  
Fax: +27 (0)13 246 1205


## CAPE TOWN

Unit 1, 56 Junction Street  
Parow Industria  
Cape Town 7500  
Tel: +27 (0)21 951 2901  
Fax: +27 (0)21 951 2910

## PORT ELIZABETH

11 Opel Lane  
Neave Industrial Park  
7 Bennet Street  
Port Elizabeth 6020  
Tel: +27 (0)41 451 1404  
Fax: +27 (0)41 451 1406

CMG PRODUCTS ARE SOLD AND RECOMMENDED BY :



All CMG products are regularly redesigned and improved and CMG reserves the right to change the design, technical specification and dimensions without prior notice. E&OE.

CMG Aurora | LPRB 1106 (edition 1.0.0)



710-12538-00A

